




RITA-880 Tube Installation



Caution:

- 1) Never power on the amplifier without having speaker load to the amp.
- 2) Do not operate the amp when the AC voltage is deviated markedly from the prescribed voltage. It had better operate the amp by AC power no more than 5% deviation from the prescribed voltage. If the household AC power has a fluctuating voltage and exceeds the limit frequency, it's important to use a power conditioner with the amp. Check Grant Fidelity website for power conditioning products.
- 3) The amp must be placed at a well ventilated place to facilitate heat dissipation.
- 4) Never spill liquid onto the tubes, especially when the amp is operating. If it happens, check with a technician before you power on the tube amp again.